# OXYGONO MICTO MIST Showor

Handing instructions

**Arromic** 





# 3 types of water flow clean the skin softly

Slide switch for easy one-hand operation You can enjoy 3 types of mode (shower, mist, jet)





Farming Tropical Rain (lower button / shower)

mist



Alps morning haze ( middle button / mist)

#### Je.



Relaxing wavy jet (upper button / lower)

### **Farming Tropical Rain**

Uses a large dropslet shower that can wash wide areas at once. A jet of comfortable water envelops your entire body. Reminiscent of luxury hotel or spa, you can enjoy a luxurious bathing experience.



Tropical Rain

## Alps morning haze

A refreshing spray of mist that resembles the morning fog og the Alps. The fine, gentle mist of water. It is less irritating to the skin and can be used comfortably even by people with sensitive or dry skin.

## Sensory mist



## Relaxing wavy jet

Altertnating left and right massage jets create an unprecedented effect.

The adjusting speed changes according to the amount of water flow and you can experience various strong and weak massage effects with the main water flow.

## Relaxing jet



## **03** Installation method

## 1 Remove your current shower head

Hold the hose connector firmly and turn the hand shower counterclockwise to disconnect the connector.



If the shower hose you are currently using has packaging, use it as is.



## 2 Apply the body

Install the shower head by turning a clockwis.





Please attach it firmly.



During installation, the seal may peel off easily. Hold the seal firmly and install it slowly so that it does not protrude.

## veuillez noter



Removing the shower head: If this is difficult, you can use rubber gloves to easily remove it.

tor

 $\subseteq$ 

## **04** Precautions for use



# This product is a shower head for the bathroom.

Please do not use it for any other purpose.





### Do not dismantle the main body.

Never remove parts other than the maintenance section. Once disassembled, it cannot be used again.



#### Do not remove a worn seal



Damage to the seal may cause water leaks



#### The water runs after use.

Droplets of water inside of showerhead may fall from the shower head after use. This is where the residual water in the head is draines off. This is not a malfunction.



# Don't subject the product to strong impact.

Failure to do so may result in irreversible damage.





#### In the event of damage.

Please refrain from using the hand shower. The main body uses a metal coating that can become sharp and dangerous.



Do not place near a fire.





#### Do not let hot water run at more than 60°C

This cloud lead to distortion, etc.



#### Use within the applicable flow rate (12 litres pre minute)

Excessive flow rates can cause serious damege, etc.



# Do not use anything that distorts or ficvolours the resin.

Mold strippers, alcohol-based detergents, etc. Can deform or discolour the resin.



ARROMIC A MONDIAL M WELLNESS W